AWDis Just Hoods – Cross Neck Hoodie

Size guide · style JH021 (JH021)

GS WORKWEAR & TOOLS

Size	S	M	L	XL	2XL	TOL + / -
Chest	48	53	58	63	68	2
Body Length (HPS)	68	71	74	77	80	2
Sleeve Length	70	71.5	74	75.5	77	2

Source: AWDis Just Hoods official size guide, via Ralawise. Garment measurements in cm. Tolerance shown in the last column.